


Rutland FM1803 Furlmatic Windcharger **inc. MPC1 Controller** **Owners Manual**



CONTENTS

	Page
INTRODUCTION.....	3
CHECK YOU HAVE RECEIVED.....	4
WHAT YOU WILL NEED, TOOLS, OTHER.....	4
SITING THE WINDCHARGER.....	5
SYSTEM DESCRIPTION & PRINCIPLE OF OPERATION.....	6
Aerofoil Blades	
Generator	
Tail Assembly	
Control Unit	
MOUNTING TOWER	10
ASSEMBLY & INSTALLATION.....	12
Blade Assembly.....	12
Turbine Assembly.....	13
Tail Assembly.....	14
Tower Preparation.....	15
Control Unit Installation.....	16
BATTERIES.....	17
CABLE SPECIFICATION.....	18
ELECTRICAL CONNECTION.....	19
FITTING GENERATOR TO THE TOWER.....	20
Final Mechanical check.....	20
UP AND RUNNING.....	21
SPECIFICATION AND PERFORMANCE.....	22
INSPECTION AND MAINTENANCE.....	23
TROUBLESHOOTING.....	24

INTRODUCTION

This manual contains important information concerning your Rutland FM1803 Windcharger system and its installation and operational characteristics.

It is strongly recommended that you read this manual and familiarise yourself with its contents before installing and operating the Windcharger system.

The Rutland FM1803 Furlmatic Windcharger is designed to provide a direct current (DC) power supply via a battery bank for low voltage equipment, lighting, inverters etc. in domestic and professional applications.

WARNING!

- *When turning, the Windcharger is capable of generating voltages in excess of the nominal voltage. Caution must be exercised at all times to avoid electric shock.*
- *Never disconnect the batteries from the controller when the turbine is running.*
- *The wind generator must never be operated on open circuit, (ie without control unit connected, since hazardous voltages can be generated.*
- *No attempt to work on the system should be made until the wind generator is restrained from turning.*
- *The Windcharger is fitted with ceramic magnets which can be damaged by heavy handling. The main generator assembly should be treated with care during transit and assembly.*
- *It is essential to observe the correct polarity when connecting the Windcharger and all other components into an electrical circuit. Reverse connection will damage the Windcharger system and invalidate the warranty.*
- *Do not adjust the settings on the control unit without reference to the manufacturer.*
- *If in doubt, refer to your dealer, a competent electrical engineer or the manufacturer.*

CHECK YOU HAVE RECEIVED

- Two (2) Aerofoil Blades and 10 nuts and bolts
- Main Generator Assembly
- Tail Fin assembly and Fixings
- Spinner and fixing stud
- Control Unit – *Check that the voltage indicated on the connection label and the side of the housing corresponds with your battery voltage.*
- 3 Way Connector Block

In the event of loss or damage, consult your dealer or the manufacturer.

WHAT YOU WILL NEED

Tools

- Suitable wire stripper
- Small terminal screwdriver
- Phillips (cross-head) screwdriver
- 2 x 13mm spanners or sockets
- 36mm spanner or socket
- 10mm spanner or socket
- 8mm Allen key
- 6mm Allen key

Other Items You Will Need

- Mounting tower
- Winch or other suitable lifting/pulling equipment
- Cable
- Batteries
- Battery terminals
- Connector blocks (as determined by your total system)
- Suitable fixings for wall mounting control unit.

Please complete the system details in the maintenance schedule (appendix A). This information is important & should be kept safe & available if contacting the manufacturer for advice or technical information.

SITING THE WINDCHARGER


The location and height of the mounting pole or tower for your wind turbine will be the major factor in the overall performance of your system.

The smooth flow of wind over land and water is often interrupted by a multitude of obstructions causing wind shear and turbulence.

Wind shear describes the interference between the fast moving upper air and the slow moving air close to the ground and the resulting decrease in average wind speed as one gets closer to the ground.

Turbulence is caused by the wind passing over obstructions such as trees and buildings. Both wind shear and turbulence diminish with height and can be overcome simply by putting the machine sufficiently high above them.

It is therefore essential that the wind generator should be located in an area as free as possible from disturbed wind flow. Bear in mind that downwind obstructions can be as detrimental to performance as upwind obstructions (Fig.1).



SYSTEM DESCRIPTION & PRINCIPLE OF OPERATION

Aerofoil Blades & Rotor

The 1803 rotor consists of 2 glass fibre composite aerofoil blades rigidly fixed to a hub. The blades are at an optimum fixed pitch for variable speed operation over a wide wind speed range. During operation, the rotor can rotate at high RPM, the leading edge of each blade will strike any airborne solid particles, eg sand, grit, hail, etc at high velocity, the impact could cause damage to an unprotected blade in a similar fashion to sand blasting. For this reason the leading edge of each blade is protected by a special tape designed for this purpose. It is important that this tape is inspected regularly and replaced as necessary in order to ensure long blade life. *Please see Inspection & Maintenance section on page 22.*

Generator

The rotor is rigidly attached to the generator shaft providing direct drive to the 3 phase brushless permanent magnet ac generator, producing variable frequency ac at approx 120v L-L under normal conditions. **Note: the generator must not be allowed to run open circuit since high voltages can be generated.**

Yaw system

The complete wind generator assembly is mounted on yaw bearings allowing free rotation on it's vertical axis to enable it to respond to changes in wind direction. The yaw assembly also includes a slipring & brush system to transmit the generated current to the fixed transmission cable while allowing free 360° yaw rotation.

Tail assembly

The inclined tail fin is hinged to the rigid tail boom on durable sleeve bearings. The tail is designed to direct the turbine into the main direction of wind at wind speeds up to approx 35mph, above this the automatic 'furling' mechanism will turn the generator at an angle to the wind to protect the generator, turbine & supporting structure from severe winds. During furling the output power will be reduced. When the high wind subsides, the tail assembly will automatically return the turbine to normal operation. In turbulent conditions the system may be seen to repeat this cycle many times.

Control Unit

The 1803 MPC1 control unit controls the operation of the FM1803 wind generator & protects the battery bank from overcharge.

The 3 phase transformer & full wave bridge rectifier convert the raw generated 3 phase ac to dc at a level corresponding to the battery voltage.

The microcontroller based electronic controller monitors the battery voltage, charge current & temperature. At pre-set levels, the controller will switch the generator between Low and High wind modes to ensure optimum performance.

When the battery voltage reaches a level indicating fully charged, the controller switches the generator to 'stalled' mode causing the generator RPM to reduce to a slow idle, preventing further power being generated into the battery bank. When the battery voltage falls to a lower pre-set limit, the control unit will automatically switch back to 'charge' mode. *Unless otherwise specified at the time of order, the limits will be set for lead acid batteries (upper limit 2.4v/cell & lower limit 2.08v/cell @ 25°C). If other types of battery are to be used or other settings are required, contact the manufacturer for advice.*

When in 'stalled' mode, the system can be manually re-set to 'charge' mode by pressing the reset button on the front panel.

Temperature compensation ensures that the battery voltage switching points are automatically adjusted for ambient temperature to maintain optimum battery performance.

A digital LCD display shows battery voltage, charge current, generated power, operating mode & warnings. Coloured LEDs also indicate operating status & warnings.

The on/off switch on the front panel allows the control unit to be switched off which will select 'stalled' mode for installation / servicing, stalling the turbine to a slow idle & preventing power being produced. In this mode the LCD display will be blank.

If a battery is not connected, the control unit will default to stall mode.

There are 3 continuous operating modes:

Mode	Low/High LED	Charge/Stall LED	LCD Display
Charge Low Wind	Green	Green	Charge Low Wind
Charge High Wind	Red	Green	Charge High Wind
Stalled	Red	Red	Turbine Stalled

Transitional modes indicated by LEDs:

Charge/Stall LED Flashing Green/Amber – Currently in charge mode, the battery voltage has reached the fully charged level & a time delay period has started prior to entering stall mode, the voltage must remain at this level for the whole of the time period before a mode change will take place. If the voltage falls again while in this phase, the LED will stop flashing & the controller will stay in charge mode. This is to prevent unnecessary change of mode during transient voltage changes.

Charge/Stall LED Red/ pulsing off once per second – The Controller has switched to stall mode & a time delay period has started to allow the turbine to stabilize in the new operating mode before re-checking the battery voltage.

Charge/Stall LED Flashing Red/Amber – Currently in stalled mode, the battery voltage has reached the lower voltage limit & a time delay period has started prior to entering charge mode, the voltage must remain at this level for the whole of the time period before a mode change will take place. If the voltage rises again while in this phase, the LED will stop flashing & the controller will stay in stall mode. This is to prevent unnecessary change of mode during transient voltage changes.

Charge/Stall LED Green/ pulsing off once per second – The Controller has switched to charge mode & a time delay period has started to allow the turbine to stabilize in the new operating mode before re-checking the battery voltage.

Low/High Wind LED Flashing Green/Amber – Currently in Low wind mode, the charge current has reached the upper limit for low wind mode & a time delay period has started prior to entering High wind mode, the current must remain at this level for the whole of the time period before a mode change will take place. If the current falls again while in this phase, the LED will stop flashing & the controller will stay in Low wind mode. This is to prevent unnecessary change of mode during transient current changes.

Low/High Wind LED Red/ pulsing off once per second – The Controller has switched to High wind mode & has started a time delay period to allow the turbine to stabilize in the new operating mode before re-checking the charge current.

Low/High Wind LED Flashing Red/Amber – Currently in High wind mode, the charge current has reached the lower limit for high wind mode & a time delay period has started prior to entering Low wind mode, the current must remain at this level for the whole of the time period before a mode change will take place. If the current increases again while in this phase, the LED will stop flashing & the controller will stay in High wind mode. This is to prevent unnecessary change of mode during transient current changes.

Low/High Wind LED Green/ pulsing off once per second – The Controller has switched to Low wind mode & has started a time delay period to allow the turbine to stabilize in the new operating mode before re-checking the charge current.

Note: High/Low wind mode switching is inactive when the controller is in Stall mode. In Stall mode, high wind mode will also be selected to prevent high transient currents if the controller switches back to charge mode during high winds.

Warnings

Mode	Low/High LED	Charge/Stall LED	LCD Display
Low Battery Volts	Flashing Red	Flashing Red	Warning: Low Bat
Over Temperature	Flashing Red	Flashing Red	Over Temperature

Both Leds flashing alternately Red & LCD display ‘Warning: Low Bat’ – Battery voltage is below the minimum recommended level & is therefore seriously discharged, any loads should be removed & the batteries recharged as soon as possible to avoid permanent damage to the battery.

Both Leds flashing alternately Red & LCD display ‘Over Temperature’ – The internal components of the control unit have reached a higher than normal temperature. The turbine will be stalled and the cooling fan will run until the temperature has reduced to normal levels when the turbine will resume normal operation. If this occurs, check that the controller housing vents are not obstructed.

The control unit has a built in cooling fan which will only operate when the internal temperature of the control unit exceeds a pre-set level. This will only normally operate during periods of high generated power levels.

MOUNTING TOWER

The Rutland 1803 is designed to fit inside a round tube with an internal diameter of 81mm.

A suitable mounting pole can be erected using 80mm (3[⁄]4") galvanised (medium) tube to BS1387 a minimum height of 6.5m, 10m or greater is recommended. The tube must be supported by a minimum of 2 sets of four guy lines.

The attachment points for the guy lines to the tower should be securely fixed to the tower.

- All items should be galvanised or stainless steel for protection against corrosion.
- Where guy lines are looped, the loop must incorporate a thimble and be fitted with a minimum of three rope grips.
- All ground fixings must be made suitable according to the ground conditions.

Pivot type towers are recommended as these allow for easier installation and lowering for access to the wind generator for maintenance. A form of pivoting tower is suggested in Fig 2. Non-guyed pivoting towers are available, for further tower details contact the dealer or manufacturer.





Fig 2. Typical Tower

ASSEMBLY AND INSTALLATION OF THE WINDCHARGER

Blade Assembly

Assemble the two turbine blades to the main hub and front hub plate ensuring that the flat surface of the blade faces the front plate of the assembly as shown in Fig 3, fit the 10 (5 per blade) M8 x 65 bolts from the rear of the assembly & fit the 10 M8 lock nuts. Tighten the bolts each a little in turn to a final torque of 20 Nm.




Fig 3. Turbine Blade Assembly

Turbine Assembly

Ensure the key is fitted to the keyway of the windshaft extension of the main generator assembly. Slide the turbine assembly onto the windshaft aligning the hub keyway with the key. **Ensure the flat surface of the blades faces away from the nacelle.** Fit the M24 spring washer and M24 Nut & tighten.

Check tightness of all screws. (Do not over-tighten).

Fit the aluminium spinner in position on the front of the generator hub and secure in place with the M6 stud and nut provided.

Alternatively the turbine and spinner can be fitted after mounting the generator assembly to the tower.




Fig 4. Turbine Assembly Fitting

Tail Assembly

Insert the tail assembly into the end of the tail boom, aligning the threaded holes in the tail mounting with the clearance holes in the tail boom. Insert the two M10 x 16 Button Cap Screws & Shakeproof washers & tighten to a torque of 20Nm. When fitted, the tail fin will be inclined 15° to the vertical.




Fig 5. Tail Assembly

Tower Preparation

- The post adaptor fitted to the 1803 is designed to fit inside a standard 81mm (3") internal diameter tube. The adaptor is provided with a flat on one side to clear the weld seam on seamed pipe.
- Mark and centre-punch four positions diametrically opposite, at 45° to the pipe seam if necessary, 20mm from the top of the tube.
- Drill four holes 12.5mm in diameter on centre-punch positions & remove burrs.




Fig 6. Tower Preparation

Control Unit Installation

The Control unit should be installed as close as possible to the batteries to minimise the length of the main battery leads, at the same time the unit should be protected from battery fumes from vented batteries.

Ensure adequate ventilation is provided to allow efficient heat dissipation via the control unit vents. These vents must not be covered or obstructed.

The unit is not weatherproof & therefore must be suitably protected.

Mount the unit securely to a wall or other vertical surface, using the mounting holes provided, in a suitable location allowing for cable entries in the base of the unit. The cable entries are fitted with blanking grommets which need to be pierced or can be removed for attachment of 20mm conduit fittings if required.






Fig 7. Control Unit

BATTERIES



Leisure/Deep Cycle batteries are specifically designed for good performance in terms of charge/discharge cycles. Batteries are the most important part of your battery charging system and should be sized according to your load requirements and provide at least 3 days reserve capacity. This will reduce cycling, prolong the life of the battery and ensure system reliability during periods of low wind. *If in doubt about battery sizing, contact your dealer or the manufacturer.*

The minimum battery capacity recommended is 400Ah @ 12v, 200Ah @ 24v

Permanent connections should always be made to the battery terminals. Never use crocodile clips or similar devices. Battery terminals should be well greased with petroleum jelly or similar.

Batteries may be linked as follows:

- In parallel to increase amp hours (Fig.8).
- In series to increase voltage (Fig.9).
- A combination of series & parallel to achieve desired voltage & capacity.

Only batteries of similar type & capacity & ideally the same manufacturer should be connected together in series or parallel.

Ensure the voltage indicated on your controller corresponds with your battery voltage.

CABLE SPECIFICATION

The cable size used for connection of the Windcharger to the control unit should be in accordance with table 1 in order to minimise voltage drop and ensure optimum performance. 3 cores will be required.

Cable Run (m)	Minimum Cable Size	
	(mm ²)	AWG
Up to 50	1.5	16
Up to 100	2.5	14
Up to 150	4	12
Up to 250	6	10
Up to 450	10	8
Up to 700	16	6
Up to 1000	25	4

Table.1

The cable size for connection of the control unit to the batteries should be 10mm² minimum; the use of smaller cables than recommended will reduce the performance of the charging system.

The type of cable is dependent on the type of installation & national or local wiring regulations. **All cables must be suitably protected from mechanical damage.**

All cables & installation should be in accordance with IEE Wiring regulations

The 3 phase cable from the WG is coloured in accordance with amendment 2 to BS7671: 2001 (IEE wiring Regulations 16th Edition).

Phase 1- Brown

Phase 2 - Black

Phase 3 - Grey

ELECTRICAL CONNECTION

- Remove the four screws from the control unit front panel, carefully remove the front panel by sliding upwards to release the latches into the main housing, withdraw until the ribbon cable connecting the front panel to the main housing can be accessed. Unplug the ribbon cable from the PCB in the main housing & the front panel can then be removed.
- Using the cable selected (see Table 1), pass the cable through the inside of the tower & route to the control unit. Leaving sufficient length of cable protruding from the top of the tower to enable easy connection to the wind generator.
- Pass the cables through the grommet or conduit in the base of the control unit & connect to the 3 terminals labelled for the wind generator. (*The generator output is 3 phase ac, therefore these connections can be made in any sequence*).
- Using the cable selected for connection of the control unit to the batteries. Pass the cables through the grommet or conduit in the base of the control unit & connect to the 2 terminals labelled for the battery. **It is vital to observe correct polarity when connecting the battery cables otherwise serious damage will result.**
- Re-connect the ribbon cable & re-fit the control unit front panel. Move the ON-OFF switch to the 'OFF' position.




Fig 10. 12 & 24v Control Unit Connections

FITTING THE GENERATOR TO THE TOWER

- Connect the wind generator flying leads to the cable protruding from the tower using the connector block supplied or other suitable connector. *(The generator output is 3 phase ac, therefore these connections can be made in any sequence).* Wrap the connection with insulation tape to secure/protect from the environment. *It is recommended that cable restraint is fitted to prevent the weight of cable applying excessive load to the connections, a simple method of achieving this is shown in Fig 11.*




Fig 11. Cable strain relief

- Carefully locate the wind generator post adaptor into the top of the tower ensuring the flat on the post adaptor aligns with the pipe seam if necessary.
- Push the adaptor into the tower while the cable is gently pulled from the tower base to ensure it is not trapped, continue until the post adaptor is fully inserted into the tower and the fixing holes align.
- Secure the wind generator to the tower using the four M12 x 25mm screws and shakeproof washers provided. Tighten using an 8mm Allen key.

Final Mechanical Check

- Check the tightness of the blade screws and nose dome.
- Check the free rotation of the hub and yaw axis.
- Check for free movement of the tail fin.

UP AND RUNNING


- Before raising and securing the wind generator, check that:
 1. All final mechanical checks have been made.
 2. The cable is not trapped.
 3. All electrical connections are secure and safe.
 4. The switch on the control unit is in the “OFF” position.
- The wind generator can now be raised into position.

Take care to avoid all moving parts when raising and lowering the wind generator.

- When raised, secure the structure firmly in an upright position. The performance of your Windcharger can be impaired if the pole is not vertical.
- Connect the battery cables to the battery terminals using suitable permanent connections. **It is vital to observe correct polarity when connecting the batteries otherwise serious damage will result.**
- Move the switch on the control unit to the “on” position. If there is sufficient wind the turbine should now accelerate and the LCD should display the current operating conditions.

SPECIFICATION AND PERFORMANCE

The curve shown below is for ideal, non-turbulent wind conditions; this may not be achieved in some installations.



INSPECTION AND MAINTENANCE

To ensure long trouble free service from your 1803 wind generator, it is important to determine a suitable inspection & maintenance schedule. Maintenance intervals and requirements are specific to individual installations & site conditions & therefore must be determined by the user during the first year of service.

It is recommended that during the first year following installation that inspections & necessary maintenance are carried out at 3, 6 & 12 months, the results of which are used to determine future scheduled maintenance. A maintenance schedule sheet is provided for convenience. It is recommended that the maintenance schedule is completed & kept safe, & available if contacting the manufacturer for advice or technical information.

From the findings of the 3, 6 & 12 months inspections, the user should determine a suitable service interval.

- Before inspection, the turbine should either be lowered to the ground or secured to prevent the generator from turning. To stop the generator from turning proceed as follows:

Note: For safety reasons maintenance should not be attempted during strong winds.

- Move the switch on the control unit to the “OFF” position. The turbine rpm should reduce to a slow idle.
- Whilst the generator is in “stall” mode, it can be lowered to the ground or blades restrained from turning.

Blade leading edge tape must be checked for signs of wear, damage, cracking or peeling. If any of these are observed, it must be replaced before allowing to return to service. Always replace on both blades at the same time. Only the correct tape must be used, available in replacement kits from Marlec, Part No 970-009.

TROUBLESHOOTING

In the unlikely event that your Rutland 1803 should develop a defect, the turbine should either be lowered to the ground or secured to prevent the blades from turning before the following inspection is carried out.

1. Read the ‘Electrical Connection’ and ‘Up and Running’ sections and be satisfied that your system complies.
2. If your Rutland 1803 fails to turn, turns slowly or produces low output, check the following:
 - **Is there sufficient wind?** The Rutland 1803 needs 3m/s wind speed to start charging. The wind speed across the turbine blades may be greatly reduced in a built-up area compared with weather reports.
 - **Is the On/Off switch in the ‘ON’ position?**
 - **Is the battery fully charged?** Check the control unit LEDs, when the red LED is lit it indicates that the battery is fully charged & the wind generator will be in “stall” mode.
 - **Is a battery connected to the control unit?** Check the control unit LEDs, if no LED is lit this indicates no battery connection to the control unit & wind generator will be in “stall” mode.
 - **Is the battery in good condition?** Check the voltage and electrolyte level of each battery.
 - **Check electrical continuity** throughout the system, especially look for corrosion and poor connections in cable joints and connector blocks.
 - **Check the brushes and slipring for wear or damage.** To inspect the brushes, remove the nacelle by removing the three fixing screws and slide nacelle backwards towards the tail fin. The brushes and slipring can be inspected. Remove any black deposits from slipring with emery paper.
 - **Check hub for free rotation with generator disconnected from control unit.** If the hub does not rotate freely, check for a possible short circuit in the wiring. If no wiring fault is found refer to your dealer or manufacturer.

If in doubt, refer to your dealer or manufacturer.

FM1803 Maintenance Schedule (1st 12 months)

System Details			
Generator Serial Number		System Voltage	Remarks
Control Unit Serial Number		Battery Capacity	
		Battery Type	
		Tower Height	

Date of Installation		Service Interval	
----------------------	--	------------------	--

Check	3 months		6 months		12 months	
	Date	Remarks	Date	Remarks	Date	Remarks
Blade Leading edge tape						
Blade Bolts						
All other nuts & bolts						
Turbine for smooth free rotation						
Yaw axis for smooth free rotation						
Tail hinge for smooth free rotation						
General Condition						
Tower assembly condition						
Guy wire tension (if applicable)						

FM1803 Maintenance Schedule

System Details			
Generator Serial Number		System Voltage	
Control Unit Serial Number		Battery Capacity	
		Battery Type	
		Tower Height	
Remarks			

Date of Installation		Service Interval	
-----------------------------	--	-------------------------	--

Check	Date	Remarks	Date	Remarks	Date	Remarks
Blade Leading edge tape						
Blade Bolts						
All other nuts & bolts						
Turbine for smooth free rotation						
Yaw axis for smooth free rotation						
Tail hinge for smooth free rotation						
General Condition						
Tower assembly condition						
Guy wire tension (if applicable)						

LIMITED WARRANTY

The Marlec Engineering Company Limited Warranty provides free replacement cover for all defects in parts and workmanship for 12 months from the date of purchase. Marlec's obligation in this respect is limited to replacing parts which have been promptly reported to the seller as having been in his opinion defective and are so found by Marlec upon inspection.

Defective parts must be returned by prepaid post to Marlec Engineering Company Limited, Rutland House, Trevithick Road, Corby, Northamptonshire, NN17 5XY, England, or to an authorised Marlec agent.

This Warranty is void in the event of improper installation, owner neglect or natural disasters and does not extend to support posts, inverters or batteries.

No responsibility is assumed for incidental or consequential damage, damage caused by the use of any unauthorised components.

No responsibility is assumed for non "furling" versions of the Rutland Windcharger (ie. the Standard and Marine generators) where Marlec or one of its authorised agents finds that a generator incorporating a furling device should have been used.